



# CP Mobile Quick Features Guide

## Payment

Enter machine number or scan Reader QR code to select an available machine.

Load laundry and then tap **Confirm**.


Depending on your machine type, you will either select your fabric setting or push the start button on the machine.



## Request Service

Tap on the **Request Service** icon and select **I have an issue with the laundry machine**.

Simply enter machine position number or scan card reader QR code, and fill out the description field.



## Cycle Notifications

Get notified when your cycle is complete from where ever you are!



## Help

Tap on the hamburger menu in the upper left corner and select **Help** to access our helpful FAQ's.

